



### Tips for setting the span and Run Points

The span points are set parallel to the girder with the Start Span (1) should be placed at the corner of the walls typically where the hip jack will be located. End Span (2) should be located where the last end jack will be placed.

The run points should be positioned so that they are perpendicular to the girder truss. Locate Start Run (3) in the same position as Start Span (1). Locate the End Run (4) at the intersection of the wall and girder truss.

The span dimension should be greater than the distance from the wall to the intersection of the hip ridge line and the girder truss.





We hope you found this topic valuable. If you have any questions or a suggestion for an upcoming article please email us at [training@alpineitw.com](mailto:training@alpineitw.com).

For technical assistance, please call the Alpine Help Desk at (866) 237-2878.

[Website](#)   [Products](#)   [Services](#)   [Resources](#)   [About](#)   [News & Events](#)